


MoniServ, Inc | www.lcdparts.net
1600 Noriega street | San Francisco | CA 94122 | 1-888-785-7288

How to connect to the existing inverter wire harness

To fire up LED backlight, All you need to do it apply +12V (+12V to + 24V DC) to Red wires and Negative (Ground) to Black wires. That's it. It is easy to install. Anyone can do it!



MoniServ, Inc | www.lcdparts.net
1600 Noriega street | San Francisco | CA 94122 | 1-888-785-7288